

Thank you for choosing Airsight as your IP WIFI Camera.

This guide is designed to help you set up your camera and view it wirelessly on your Apple or Android device as fast as possible.

Set up is simple and only takes minutes.

For additional help, please try our FAQ pages located at:

http://kbase.x10.com/wiki/IP_Cameras

2

Setting up the Software (android / ios)



3. Install the Apple or Android App from the Apple App or Google Play Store
4. Open the App to set up camera
 - a. Click the  "Add Camera" button
 - b. Click "QRCode"
 - c. Allow the App to access your camera and hover the box over the QR Code on the bottom of the Airsight Camera
 - d. The default password for the camera is 000000

1

Setting up the Hardware

1. Unpack Product
2. Attach the wireless antenna to the back of the camera
3. Use the included AC Adapter to plug in the camera to power
4. Plug the camera into your router with the supplied Ethernet cable



3

Going Wireless with the Airsight

5. To set up the camera for wireless viewing:

While the camera is still plugged into the router:

 - b. In the App, Click on the  'information' button next to the camera you are setting up.
 - c. Go to > "Advanced Setting"
 - d. Click on "WiFi" and select your WiFi network and input password.
6. Detach Camera, place where you wish and plug in power. Allow a couple minutes for the Camera to reboot.

You are now Wireless!