



The WS14A Decorator Companion Switch **MUST** be used with an X10 Primary Switch (like the WS12A or XPDi3). The WS14A is normally used for what is referred to as "3-way" applications (where you have two switches controlling the same light, at the top and bottom of a staircase, for example). Refer to the instructions supplied with the X10 Primary Switch for more details. The WS14A can also be used for 4-way applications (where 3 switches control the same light). For 4-way applications, connect the X10 Primary Switch and one WS14A as per the instructions, then connect an additional WS14A as shown in the diagrams above.

**WARNING: Wall Dimmer Modules must not be used to control appliances or Alternative Lighting (LED, Fluorescent, Halogen, etc)**

**IMPORTANT:** Some X10 Master Switches require a Neutral connection. This is NOT the same as ground. If you are unsure whether or not you have a Neutral wire at the switch location, consult a qualified electrician.

**Installing an additional Companion Switch (4-way applications)**

- Disconnect the power at the circuit breaker.
- Remove all wall plates and unscrew the existing switches from their boxes. Identify which switches are three way switches (3 screw terminals) and which switch is a 4-way switch (4 screw terminals). Identify the common wire at each existing 3-way switch (usually connected to a different color terminal).
- Replace the existing Primary 3-way wall switches with the X10 Primary Wall Switch as per the instructions that came with that switch.
- Replace the other existing secondary switches with the WS14A Companion Switch.
- Make sure any unused wiring is safely capped and screw all switches back into their wall boxes and replace the wall plates.

**120 DAY LIMITED WARRANTY** x10.com (X10), a division of Authinx Inc., warrants this product to be free from defective material and workmanship for a period of 120 days from the original date of purchase at retail. X10 agrees to repair or replace, at its sole discretion, a defective product if returned to X10 within the warranty period and with proof of purchase. If service is required under this warranty:

Call 1-888-384-0969, visit [www.x10.com](http://www.x10.com), or email [support@x10.com](mailto:support@x10.com).