


Slave Switch

WS14A

WS14A Slave Switch has no load bearing capacity and only operates in conjunction with the WS13A 20A Master, WS16A Inductive Dimmer or the WS12A Incandescent Dimmer Switches.



Description: The WS14A Slave Switch works with the WS13A, WS12A and WS16A Master Wall Switches to complete a 3 or 4-Way installation. The WS14A sends a 120Volt pulse from its Switch Terminal to the Master Switch's Control Terminal via one traveler wire. Dimming can be performed from either the WS14A or the Master Switch location as long as the load attached to the Master is dimmable, and you must use either of the WS16A or WS12A Master Dimmer Switches. The Master Switches perform all the load control, the Slave simply tells the Master to turn ON/OFF or Brighten/ Dim as applicable to the installation.

Specific Requirements: 120VAC

Optional / Supplementary Devices & Modules:

WS13A 20A Wall Switch, WS16A Inductive Dimmer Wall Switch and WS12A Incandescent Dimmer for existing 3 or 4-Way Installations.

Installation:

For specific wiring connections, see installation Instructions for WS13A 20A Wall Switch, WS16A Inductive Dimmer Wall Switch and WS12A Incandescent Dimmer Switch.

Note: The WS14A does NOT require any X10 Code Addresses; it is simply a Slave Switch to communicate to the Master Switch. All Address Codes and Switching is performed on the Master Switch.

120 DAY LIMITED WARRANTY x10pro-usa.com (X10PRO-USA), a division of Authinx Inc., warrants this product to be free from defective material and workmanship for a period of 120 days from the original date of purchase at retail. X10PRO-USA agrees to repair or replace, at its sole discretion, a defective product if returned to X10PRO-USA within the warranty period and with proof of purchase. If service is required under this warranty:

Call 1-888-384-0969, visit www.x10pro-usa.com, or email support@x10pro-usa.com